




FRANCE DESIGNED

Diamond
Carry Cot
USER MANUAL



www.jikelbaby.com

IMPORTANT
Retain for Future Reference & Read Carefully



Max 9 kg

Maintenance

-ALWAYS CHECK THE CARRY COT, IF THERE ARE LOOSE SCREWS, PARTS ARE AGING, MATERIALS AND SEWING THREADS ARE BROKEN, PLEASE REPLACE AND REPAIR IF NECESSARY.

-WIPE THE CARRY COT WITH A DAMP CLOTH AND A MILD DETERGENT.

-CLOTH COVER AND CANOPY ARE NOT MACHINE WASHABLE. IN ORDER TO AVOID DAMAGE TO THE SURFACE OF THE CLOTH, DO NOT BRUSH THE CLOTH COVER HARD.

-LEAVE THE WASHED CLOTH COVER IN A VENTILATED PLACE AND DRY IT. DO NOT EXPOSE IT TO THE SUN.

-ALWAYS CHECK THE FLEXIBILITY OF THE LOCKING DEVICE AND THE STABILITY OF THE BASIC PARTS.

WARNING!

- WARNING! NEVER USE THIS CARRY COT ON A STAND.
- WARNING! THIS PRODUCT IS SUITABLE FOR A CHILD WHO CANNOT SIT UP UNAIDED. THE MAX WEIGHT OF THE BABY IS 9 kg.
- WARNING! USE ONLY ON A FIRM, HORIZONTAL, LEVEL AND DRY SURFACE.
- WARNING! DO NOT LET OTHER CHILDREN PLAY UNATTENDED NEAR THE CARRY COT.
- WARNING! DO NOT USE IF ANY PART IS BROKEN, TORN OR MISSING.
- WARNING! NEVER LEAVE YOUR CHILD UNATTENDED.
- WARNING! ENSURE THAT ALL LOCKING DEVICES ARE ENGAGED BEFORE USE
- WARNING! DO NOT USE THE PARTS PROVIDED BY NON-MANUFACTURER.
- WARNING! THE HANDLES AND THE BOTTOM OF THE CARRY COT SHOULD BE INSPECTED REGULARLY FOR SIGNS OF DAMAGE AND WEAR.
- WARNING! WHEN INSTALLING THE CARRY COT, BE SURE TO HEAR A CLEAR "BEEP" SOUND. BEFORE USE, LIFT THE CARRY COT UP AND MAKE SURE THE CARRY COT IS IN PLACE.
- WARNING! BEFORE CARRYING OR LIFTING, MAKE SURE THE HANDLE IS IN THE CORRECT POSITION AND LOCKED.
- WARNING! A STATEMENT THAT THE HEAD OF THE CHILD IN THE CARRY COT SHOULD NEVER BE LOWER THAN THE BODY OF THE CHILD.
- WARNING! A STATEMENT TO NOT ADD ANOTHER MATTRESS ON TOP OF THE MATTRESS PROVIDED OR RECOMMENDED BY THE MANUFACTURERS.
- WARNING! KEEP AWAY FROM FIRE.

Carry Cot Installation Instructions

Basket installation and disassembly

1. Installation: insert the support rods at both ends of the basket into the blanks until they are completely stuck in the groove, as shown in Figure 1 : Finally, the canopy, lining and seat Pull the zipper between them.

2. Disassembly: vice versa.




Figure 1

Unlock and lock the handle:

1. Unlock: Press the button on both sides in the direction of the arrow (Fig. 2) to press the unlock button. When you hear a clear "beep", it indicates The handle has been unlocked.

2, lock: pull the handle to the direction of the foot of the basket, hear a clear "beep" sound, lift the lock




Figure 2

NOTE: BEFORE LIFTING THE BASKET, MAKE SURE THE HANDLE IS LOCKED IN PLACE.

Installation and disassembly of the basket and frame:

1. The head of the basket is oriented toward the cart. The sides are aligned with the seat socket. Press the red arrow in the direction as shown in the figure. The "beep" indicates that the basket is in place.

2. Press the seat ejection button on both sides at the same time, and the sleeping basket pops up, indicating that the lock has been unlocked.




Figure 3

NOTE: BEFORE USE, LIFT THE BASKET UP TO MAKE SURE THE BASKET IS IN PLACE.