

FRANCE DESIGNED

Diamond

Stroller
USER MANUAL









WARNING!

- NEVER LEAVE THE CHILD UNATTENDED.
- ENSURE THAT ALL THE LOCKING DEVICES ARE ENGAGED BEFORE USE.
- TO AVOID INJURY ENSURE THAT THE CHILD IS KEPT AWAY WHEN UNFOLDING AND FOLDING THIS PRODUCT.
- DO NOT LET THE CHILD PLAY WITH THIS PRODUCT.
- USE A HARNESS AS SOON AS THE CHILD CAN SIT UNAIDED.
- · ALWAYS USE THE RESTRAINT SYSTEM.
- CHECK THAT THE PRAM BODY OR SEAT UNIT OR CAR SEAT ATTACHMENT DEVICES ARE CORRECTLY ENGAGED BEFORE USE.
- THIS PRODUCT IS NOT SUITABLE FOR RUNNING OR SKATING.
- THERE SHOULD HAS ADULTS TO TAKE CARE OF THEM WHEN INFANTS TAKE THE STROLLER. STRICTLY PROHIBITED THE INFANT USE THE STROLLER ALONE.
- BUCKLE RING MAY CAUSE ASPHYXIA. SO UNTIE THE SAFETY BELT WHEN YOU NEED TO STOP USING THIS PRODUCT.
- IF ANY PARTS ARE DAMAGED OR MISSING, SHOULD IMMEDIATELY STOP USING THIS STROLLER.
- FORBIDDEN TO USE THE STROLLER AS THE TOY AND FORBIDDEN TO LET THE CHILDREN TAKE CARE OF THE INFANTS WHEN THEY USE THE STROLLER.
- TO PREVENT THE DAMAGE FOR INFANTS, PLEASE PUT ATTENTION ON THEM WHEN YOU ADJUST THIS STROLLER.
- PLEASE PARK THIS AFTER THE BRAKE IS ON. AND DON'T BRAKE THE STROLLER WHEN IT IS WALKING ON THE WAY.
- FORBIDDEN THE CHILD PLAY OR STAND ON THE PEDAL.
- THIS STROLLER JUST FIT FOR 36-0 MONTHS OLD AND WEIGHT BELOW 22KG CHILD.
- THIS SEAT UNIT IS NOT SUITABLE FOR CHILDREN UNDER 6 MONTHS.
- \bullet IF THE PACKAGE, OR ATTACHMENTS, OR BOTH ARE PLACED IN THE BABY STROLLER , IT MAY CAUSE THE CART TO BECOME UNSTABLE
- THE LOAD OF THE CARRY COT IS 2 KG. IF PUT THINGS HEAVIER THAN THAT, IT MAY EFFECT THE STEADINESS OF THE STROLLER.
- IT ONLY CAN BEAR ONE CHILD IN ONE TIME. SO NEVER LET TWO CHILD OR MORE USE THE STROLLER AT THE SAME TIME.
- SHOULD ATTEND THE SITUATION ON THE ROAD WHEN PUSH THE STROLLER ON THE ROAD.
- SHOULD HOLD YOUR CHILD IN YOUR ARMS AND ATTEND THE SAFETY ALL THE TIME WHEN YO U TAKE THE STAIRS OR ELEVATOR.
- TO PREVENT THE SLIPPING OF THE STROLLER, PLEASE FASTEN THE FRONT WHEEL WHEN YOU PARK THE STROLLER ON THE TILTED ROAD.
- DO NOT USE THE PARTS PROVIDED BY NON-MANUFACTURER.
- FORBIDDEN CLOSE TO FIRE.
- PUSHCHAIR DESIGNED TO BE USED FROM BIRTH SHALL RECOMMEND THE USE OF THE MOST RECLINED POSITION FOR NEWBORN BABIES.
- A STATEMENT THAT ANY LOAD ATTACHED TO THE HANDLE AND/OR ON THE BACK OFTHE BACKREST AND/OR ON THE SIDES OF THE VEHICLE WILL AFFECT THE STABILITY OF THE VEHICLE.
- ONLY REPLACEMENT PARTS SUPPLIED OR RECOMMENDED BY THE MANUFACTURER/DISTRIBUTOR SHALL BE USED.
- AVOID SERIOUS INJURY FROM FALLING OR SLIDING OUT, ALWAYS USE SEAT BELT.
- IF YOU ADD A LOAD CARRYING ACCESSORY TO YOUR BABY STROLLER, THERE MAY BE AN UNSTABLE, DANGEROUS SITUATION.
- THE PACKING DEVICE SHALL BE ENGAGED WHEN PLACING AND REMOVING THE CHILDREN.

Daily Maintenance

- Check the stroller frequently to see if there have some screw moved, parts aging, material or sewing broken. Please replace or repair if need
- · Use the wet cloth and mild detergent to clean the stroller.
- The seat cover and canopy cover can't be washed in washing machine. Please don't wash the cover so hard to damage the surface of the fabric.
- The cloth cover can be dried in a well-ventilated place. Please don't expose them under sun for a long time.

Baby stroller assembly drawing








1. Unfold the frame

a.First open the collapse button and pull up the handle bar, unfold the frame; b.Pressing the handle bar adjusting button on the both sides can adjust the handle bar to the height you need.




2.Install the rear wheel:

Pull up the rear axle tube and make the rear wheel core full insert until hear a sound of clear"click". That means the rear wheel is installed well. Use the same way to install another rear wheel

Remove the rear wheel:

Pressing the rear wheel removed button on the bottom of the rear axle tube can remove the rear wheel.




3.Install the front wheel:

Pull up the front wheel axle tube and make the front wheel core full insert until hear a sound of clear "click". That means the front wheel is installed well. Use the same way to install another front wheel.

Remove the front wheel:


Pressing the front wheel removed button at the inside of frame can remove the front wheel.





4.Installation and disassembly of armrest components:


Make the armrest components against the armrest socket and insert them one by one. The armrest components can be pulled out and inserted on one side. You should press the armrest removed button and pull up the armrest if you need remove the armrest.



5.Install the canopy:

a.Before you install the canopy bracket base,you should distinguish the outside and the inside of the base. Then insert the base into its place on the seat.

b.Penetrate the canopy bracket twig in the canopy cover. Then put the twig aim at the canopy bracket base and insert it in the base. c.At last, hang the lock hole at the bottom of canopy on hanging column.



6. Use the canopy:

Use you hands to push the front of the canopy can open the canopy. On the contrary, can close the canopy.





7. Adjust the seat gear:

Put your thumb on the top of the seat. Use your index finger, middle finger and the third finger to hold the seat gear adjusting button and pull it out. At the same time, move the seat up or down. That can adjust the seat to different gear.

WARNING!

THE SITTING MODE IS NOT FIT FOR THE CHILD UNDER 6 MONTH OLD.




Use your hands to press the pop-up button at both sides of the seat and pull up the seat. That can remove the seat. Then turn the direction of the seat and insert the seat into the seat socket again.

ATTENTION:

THE SEAT GEAR CAN BE ADJUSTED AFTER TURNING THE DIRECTION OF THE SEAT.


9. Using of seat belt:

In order to ensure the safety of child, this chair is equipped with five-point safety belt, the left and right plugs were inserted into the central buckle, to hear a clear "click" sound. Adjust the shoulder, waist and crotch harness according to the child's body size; press and hold the one-touch release button to unlock the seat belt.









one-button release button

1&2: Shoulder adjust buckle 3&4: Waist adjust buckle

5: Crotch adjust buckle



10. Adjust the pedal:

two hands to press the pedal adjusting button at both sides of pedal and then you can adjust the position of the pedal. You pull up the pedal tube can make the pedal return to its original position.




11.Settle the direction for front wheel


Settle the front wheel to the right direction, then make the orientation piece toward to the right place and slip it down. Then the direction of the front wheel is settled. Pull up the orientation piece, the front wheel can spin 360 degree smoothly.

ATTENTION:

TO PREVENT THE SLIPPING OF THE WHEEL, PLEASE FASTEN THE FRONT WHEEL WHEN YOU PARK THE STROLLER ON THE TILTEDROAD.



Front wheel has settled the direction




Front wheel hasn't settled the direction

12. Usage of the brake:

Step on the brake pedal then the stroller will under the braking state. Uplift the brake pedal can make the stroller out of braking.

ATTENTION:


BEFORE PARKING THIS STROLLER OR MAKING THE CHILD IN OR OUT OF THE STROLLER, YOU MUSTSTEP ON THE BRAKE PEDAL.





13. Remove the mattress:

Untie the safety belt at first. Then pull out the shoulder, waist and crotch webbing from the lock hole. Then you can remove the mattress. You can install it follow the contrary order.




14. Folding the stroller:

Under the condition of folded canopy, pull up the folding button inside of the frame and push down the handle bar until the frame is folded. Then lock on the folding hook.

ATTENTION:

IF YOU WANT THE STROLLER GETTING SMALLER, YOU CAN REMOVE THE FRONT AND REAR WHEELS.



15.Stroller automatic driving safety system

indicator lights on pushing handle are as the picture 15.



Stopping indicator light

Battery indicator light



16

A. Turn on the driving safety system


Unzip the battery box behind the carry cot. And switch the power on. Then the diving safety system has turned on as picture.

B.Driving:

Use one hand or two holding the driving induction button The stroller will on the driving situation. At this time, the driving indicator light is on and the stopping indicator light is off

C. Electronic auxiliary parking:

Loosen the driving induction button, the driving indicator light will be off. As this time, when the stroller slips or moves, the electronic auxiliary parking will turn on and the stopping indicator light will be on.




ATTENTION:

IF THE STROLLER CAN'T DRIVE AFTER LOOSENING THE BRAKE, PLEASE PUSH THE STROLLER FRONT AND BACK TO UNLOCK THE STROLLER.

17.Turn off the automatic driving safety system (turn to mechanical mode)

Method 1:

press the driving induction button for 3 seconds, and step on the brake pedal by using your right foot at the same time. Then unzip the battery box and switch it to off. Then loosen the brake pedal. If the stroller moving freely, it is in the mechanical mode. If this can't work, you can use method 2.





Method 2:


step on brake pedal, unzip the battery box and switch the power to off and then to on for 3 seconds and then to off. Loosen the pedal and the stroller will be in mechanical mode.

18. Charge the battery box

Unzip the carrying basket battery box and insert one side of the stroller specialized charge cable into the charging interface and another side into adapter charger interface to connect the home power supply. When the stroller battery is charging, the charging indicator light is red and when the power is full, the charging indicator light is green.

Method 3:

When the power is low or has other special situations, please follow the arrows in Picture 16a to switch the manual brake lever to the end of the L-shape guide slot at the left and right sides of the bottom of the rear wheel and manually forced to lift the automatic driving safety system. If you need to re-use the automatic driving safety system, you can turn the both sides of the manual brake lever back to the home position



19. The disassembly and exchange of the battery

Unzip the battery box under the carry cot. Use the specialized tool or coin to screw out the slotted head screws on the surface of the battery box. Open the box and bring the battery out. Remove the battery plug and the disassembly is finished. Put the battery plug into the exchanged battery and put them into the battery box. Screw in the slotted head screws, and cover the battery box. That finished the exchange as showed in picture 18.

